



QUICK-REFERENCE ERC TIMER CONNECTION

For more detailed setup information, consult the installation guide on the Software CD, included with your ERC Drive-Thru Performance Timer.




To "Speaker" Connections
On Drive-Thru
Communications
System
for Audio Detect

NETWORK



**Solder and
tape all splices**



REMOTE DISPLAY